




LUMIDEE
stay connected

QUICK START GUIDE


Yealink W70B

Heeft u vragen?
bel naar: [073 - 751 77 77](tel:073-7517777) of
mail naar: support@lumidee.nl




Controle

Controleer de verpakkingen of alle bestelde producten aanwezig zijn:
Basisstation W70B
4G Router (indien besteld)
Headset(s) inclusief enkelvoudige lader
USB multicharger (indien besteld)
Handset (indien besteld)




Basisstation W70B

Haal de W70B basisstation en de meegeleverde stekker uit de verpakking.
Sluit de stekkerkabel aan op de achterkant van het basisstation (1).
Steek vervolgens de stekker in het stopcontact.
Hang het basisstation zo hoog en centraal mogelijk op.




4G Router

Schroef de 3 antennes op de router: 2 op Mobile (1), 1 op WiFi (2)
Sluit de stekkerkabel met blokje met 4 pinnen (3) aan op de achterkant.
Steek vervolgens de stekker in het stopcontact.
Sluit de meegeleverde UTP kabel aan op LAN (4).
En sluit deze kabel aan op de W70B in LAN aansluiting.



Headset met enkelvoudige lader

Haal de headset en enkelvoudige lader uit de verpakking.
Sluit de stekker aan op de achterkant in DC5V (1)
Steek vervolgens de stekker in het stopcontact.
Indien u een USB-multicharger heeft besteld, sluit dan de meegeleverde USB kabel aan op PC poort (2) en daarna op de USB-multicharger.
Steek vervolgens de stekker van de USB-multicharger in het stopcontact.
Plaats de headset in de enkelvoudige lader en wacht 30 minuten.
De headset is klaar voor gebruik (of zie QSG WH62/WH63).



Handset(s)

Haal de handset en lader en de meegeleverde stekker uit de verpakking.
Sluit de kabel op de achterkant van het basisstation.
Stop de stekker in het stopcontact.
Zet de handset in basisstation.
Wacht 30 minuten.
Neem de handset uit het basisstation.
De handset is klaar voor gebruik (of zie QSG W59R).




LUMIDEE

stay connected

QUICK START GUIDE Yealink W70B


Questions?

Please call: [073 - 751 77 77](tel:073-751777)
or email: support@lumidee.nl




Checks

Check the packaging whether all ordered products are present:
Base station W70B
4G Router (if ordered)
Headset(s) including single charger
USB multicharger (if ordered)
Handset (if ordered)




Base station W70B

Remove the W70B base station and the supplied plug from the packaging.
Connect the plug cable to the back of the base station (1).
Then put the plug into the 220V socket.
Hang the base station as high and central as possible.




4G Router

Screw the 3 antennas onto the router: 2 on Mobile (1), 1 on WiFi (2)
Connect the plug cable with the 4-pin block (3) into the back.
Then put the plug into the 220V socket.
Connect the supplied UTP cable to LAN (4).
And connect this cable to the W70B in LAN connection.



Headset with single unit charger

Remove the headset and single charger from the packaging.
Connect the plug to the back in DC5V (1) and then plug the other side of the cable into the 220V socket.
If you have ordered a USB-multicharger, connect the supplied USB cable to the PC port (2) and then to the USB-multicharger.
Then put the plug of the USB-multicharger into the 220V socket.
Place the headset in the single charger and wait 30 minutes.
The headset is ready for use (or see QSG WH62/WH63).



Handset(s)

Remove the handset and base station and power cable from the box.
Connect the cable to the back of the base station.
Then put the plug into the 220V socket.
Place the handset in the base station.
Charge for 30 minutes.
Remove the handset from the base station.
The handset is ready for use (or see QSG W59R).